

WERSAL





Talerz głęboki
Plate deep
Teller tief
ø225 mm (nr 2220)



Półmis owalny
Oval dish
Platte oval
360 mm (nr 2262)
320 mm (nr 2260)
280 mm (nr 2257)
240 mm (nr 2256)



Talerz głęboki
Plate deep
Teller tief
ø200 mm (nr 2250)



Rawier
Pickle dish
Beilageplatte
210 mm (nr 2233)



Rawier
Pickle dish
Beilageplatte
245 mm (nr 2244)



Talerz głęboki z pokrywą
Plate deep with lid
Teller tief mit Deckel
ø200 mm (nr 2252)



Salaterka
Salad bowl
Salatschüssel



1,00 l, ø210 mm (nr 2221)
0,60 l, ø180 mm (nr 2218)
0,40 l, ø160 mm (nr 2216)
0,15 l, ø120 mm (nr 2217)




Talerz głęboki do deseru
Desser plate
Dessert-Teller
0,20 l, ø270 mm (nr 2249)



Miska
Bowl
Schüssel
0,35 l, ø140 mm (nr 2245)



Miska
Bowl
Schüssel
0,55 l, ø135 mm (nr 2224)
0,23 l, ø115 mm (nr 2283)



Talerz płytki
Plate flat
Teller flach
ø305 mm (nr 2243)
ø290 mm (nr 2241)
ø270 mm (nr 2238)
ø260 mm (nr 2236)
ø240 mm (nr 2234)




Czarka
Bowl
Schüssel
0,05 l, ø75 mm (nr 2207)



Talerz płytki
Plate flat
Teller flach
ø210 mm (nr 2231)
ø190 mm (nr 2230)
ø170 mm (nr 2228)
ø160 mm (nr 2288)



Pojemnik do saszetek
Tea bags box
Behälter
150 x 90 x 70 mm (nr 2276)
110 x 70 mm (nr 2278)



Półmis okrągły
Round dish
Platte rund
ø320 mm (nr 2269)



Pojemnik do saszetek
Tea bags box
Behälter
90 x 70 mm (nr 2277)



Imbryk
Coffee pot
Kaffeekanne
0,75 l (nr 2274)
0,30 l (nr 2273)



Filizanka ze spodkiem
Cup and saucer
Tasse mit Untertasse
0,25 l/ø 160 mm (nr 2201, 2214)
0,19 l/ø 145 mm (nr 2206, 2213)
0,15 l/ø 145 mm (nr 2200, 2213)
0,10 l/ø 120 mm (nr 2270, 2271)



Czajnik
Tea Pot
Teekanne
1,25 l (nr 2223)
0,40 l (nr 2222)



Filizanka ze spodkiem
Cup and saucer
Tasse mit Untertasse
0,20 l/ø 145 mm (nr 2202, 2213)



Wkład do czajnika
Teapot infuser
Teesieb für Teekanne
0,40 l (nr 0051)



Filizanka ze spodkiem
Cup and saucer
Tasse mit Untertasse
0,22 l/ø 155 mm (nr 2211, 2225)



Cukiernica
Sugar bowl
Zuckerdose
0,20 l (nr 2279)



Filizanka ze spodkiem
Cup and saucer
Tasse mit Untertasse
0,21 l/ø 155 mm (nr 2215, 2225)



Dzbanek do mleka
Milk jug
Gießer
0,30 l (nr 2205)
0,15 l (nr 2204)
0,05 l (nr 2203)



Filizanka ze spodkiem
Cup and saucer
Tasse mit Untertasse
0,16 l/ø 140 mm (nr 2242, 0371)



Sosjerka
Sauce boat
Sauciere
0,30 l (nr 2282)



Bulionówka ze spodkiem
Bouillon cup and saucer
Suppenobertasse mit Untertasse
0,32 l/ø 160 mm (nr 2227, 2214)



Solniczka
Salt shaker
Salzstreuer
0,05 l (nr 2285)



Bulionówka ze spodkiem
Bouillon cup and saucer
Suppenobertasse mit Untertasse
0,30 l/ø 160 mm (nr 2226, 2214)



Pieprzniczka
Pepper shaker
Pfefferstreuer
0,05 l (nr 2286)