

**TRAPO**





Talerz głęboki  
Plate deep  
Teller tief  
ø285 mm (nr 2138)




Talerz płytki  
Plate flat  
Teller flach  
ø305 mm (nr 2143)  
ø270 mm (nr 2038)  
ø260 mm (nr 2036)  
ø240 mm (nr 2034)  
ø210 mm (nr 2031)  
ø190 mm (nr 2030)  
ø170 mm (nr 2128)



Salaterka  
Salad bowl  
Salatschüssel  
1,10 l, ø235 mm (nr 2523)  
0,60 l, ø185 mm (nr 2518)  
0,25 l, ø140 mm (nr 2514)



Waza  
Soup tureen  
Suppenterrine  
2,70 l (nr 2564)



Talerz głęboki  
Plate deep  
Teller tief  
0,35 l, ø275 mm (nr 2134)



Talerz płytki  
Plate flat  
Teller flach  
ø290 mm (nr 2133)  
ø280 mm (nr 2136)  
ø230 mm (nr 2130)  
ø160 mm (nr 2028)



Salaterka  
Salad bowl  
Salatschüssel  
0,60 l, ø190 mm (nr 2554)  
0,50 l, ø160 mm (nr 2578)



Sosjerka  
Sauce boat  
Sauciere  
0,40 l (nr 2583)  
TRAPO BIS



Talerz głęboki  
Plate deep  
Teller tief  
0,40 l, ø240 mm (nr 4124)




Półmis okrągły  
Round dish  
Platte rund  
ø320 mm (nr 2069)



Salaterka  
Salad bowl  
Salatschüssel  
0,60 l, ø190 mm (nr 2554)  
0,50 l, ø160 mm (nr 2578)



Czajnik  
Tea Pot  
Teekanne  
1,10 l (nr 5025)  
TRAPO BIS



Talerz głęboki  
Plate deep  
Teller tief  
ø235 mm (nr 2121)  
ø225 mm (nr 2019)



Półmis owalny  
Oval dish  
Platte oval  
360 mm (nr 2162)  
320 mm (nr 2160)  
280 mm (nr 2157)



Miska  
Bowl  
Schüssel  
ø130 mm (nr 2569)



Cukiernica  
Sugar bowl  
Zuckerdose  
0,20 l (nr 2579)



Talerz głęboki  
Plate deep  
Teller tief  
0,80 l, ø220 mm (nr 2125)  
0,50 l, ø195 mm (nr 2120)  
0,50 l, ø180 mm (nr 2118)



Rawier  
Pickle dish  
Beilageplatte  
240 mm (nr 2108)



Miska  
Bowl  
Schüssel  
ø125 mm (nr 2576)



Dzbanek do mleka  
Milk jug  
Gießer  
0,20 l (nr 5006)  
TRAPO BIS



Talerz głęboki do deseru  
Plate deep for dessert  
Dessert-Teller  
0,20 l, ø270 mm (nr 2135)



Miska  
Bowl  
Schüssel  
ø125 mm (nr 2576)



Dzbanek do mleka  
Milk jug  
Gießer  
0,15 l (nr 2505)



# TRAPO



Kubek  
Mug  
Kaffeebecher  
0,40 l (nr 2516)



Filiżanka ze spodkiem  
Cup and saucer  
Tasse mit Untertasse  
0,30 l/ø 160 mm (nr 2507, 2515)  
0,20 l/ø 145 mm (nr 2503, 2512)  
0,10 l/ø 120 mm (nr 2570, 2571)



Kubek  
Mug  
Kaffeebecher  
0,35 l (nr 2520)



Filiżanka  
Cup  
Tasse  
0,30 l (nr 2509)



Kubek  
Mug  
Kaffeebecher  
0,30 l (nr 2510)  
0,20 l (nr 2549)



Filiżanka  
Cup  
Tasse  
0,20 l (nr 2501)



Kubek  
Mug  
Kaffeebecher  
0,30 l (nr 2530)



Filiżanka  
Cup  
Tasse  
0,10 l (nr 2500)



Kubek  
Mug  
Kaffeebecher  
0,40 l (nr 2592)  
TRAPO II



Spodek  
Saucer  
Untertasse  
ø 165 mm (nr 2529)



Kubek  
Mug  
Kaffeebecher  
0,35 l (nr 2508)



Spodek do jaj  
Egg saucer  
Eierablage  
ø 130 mm (nr 2587)



Kubek  
Mug  
Kaffeebecher  
0,20 l (nr 2542)



Taca  
Tray  
Stollenplatte  
350 mm (nr 2099)